

# Bear spray container made from ABS Sewer Pipe

Start by cutting the ABS pipe to length. For an 8.5 inch bear spray (including case) you will need 7.25" of ABS pipe. If your bear spray is a different length then adjust the 7.25 inch pipe length by how much your spray differs from 8.5 inches. If you want to put multiple sprays in a container simply add 8.5 to 9 inches of pipe length for each additional container. **Note that if you are using more than a 225g spray, you may need to use 4 inch inside diameter sewer pipe for all pieces!** If in doubt, cut the pipe a little long because you can always cut is shorter!

Dry fit all the pieces to ensure they fit (and that the spray fits in the container). Once you have the right fit, apply the ABS Yellow Cement according to the instructions on the can.

Place the foam in the end cap and in the top of the cleanout cap -- that's it

## Parts:

- 3 inch (inside diameter) ABS sewer pipe (12 foot lengths at Home Depot)
- 3 inch ABS endcap ("A")
- 3 inch ABS Cleanout Fitting ("B")
- 3 inch ABS Cleanout Plug ("C")
- ABS Yellow cement
- 2 pieces of foam for ends ("D")

